Collecting Your Sample



Remove any aerator or strainer attached to your faucet. Turn the cold water on so the stream is the thickness of your finger.



Let the water run gently for about five minutes to flush the pipes. Do not change the flow of water.



1) Fill your 50 mL tube to the 45 mL line. Cap your tube and wrap parafilm around the lid. This sample should be kept at room temp.

2) If you're collecting the 120 mL sample, fill it to the 100 mL line, cap it, and wrap parafilm around the lid. Freeze ONLY the 120 mL sample for 48 hours. After 48 hours, it can be kept at room temp. Write "frozen" on the label to indicate that it was frozen for 48 hrs.



Fill out the paper datasheet supplied with your sample kit and sign the permission forms. Samples will not be analyzed without these two signed documents. Register your water sample through the All About Arsenic website, unless your child is doing this at school. To register a sample yourself, go to the "For Samplers" page for a link to the Anecdata. org website and click "Add observation".



Send your sample(s) back to the project lead. Your well water will be analyzed at the Dartmouth Trace Element Analysis Core.

Results

Access your well water test results by looking up your sample number on the All About Arsenic website. Use the refrigerator magnet included in your packet to keep track of your sample number. Additional resources are available on the All About Arsenic website.

Privacy

Anecdata.org, which houses the All About Arsenic project, helps individuals and organizations collect, manage, analyze, and share scientific data. Your data are part of a larger dataset that students and teachers will analyze to come up with community-oriented solutions to well water contamination. Your name(s), exact geographic location, and any other identifying information are all PRIVATE.